



Laser Technology, Inc.

# TruSense® S100

## User's Manual



© LTI 2015 TruSense S100 0144846

 LASER<sup>®</sup>  
TECHNOLOGY  
Measurably Superior<sup>®</sup>

**Copyright Notice:**

Information in this document is subject to change without notice and does not represent a commitment on the part of Laser Technology Inc. No part of this manual may be reproduced in any form or by any means, electronic or mechanical, including photocopying, recording, or information storage and retrieval systems, for any purpose other than the purchaser's personal use, without the express written consent of Laser Technology, Inc.

Copyright (c)[2015] Laser Technology, Inc. All Rights Reserved.  
Unauthorized duplication, in whole or in part, is strictly prohibited.

Printed in the United States of America

**Trademarks:**

TruSense is trademark of Laser Technology, Inc. All other trademarks are the property of their respective owner.

**Patents:**

This product is covered by pending patent applications and/or one or more of the following issued patents: 5,612,779 and 6,445,444

**LTI Contact Information:**

Laser Technology, Inc.  
6912 S. Quentin Street  
Centennial, CO 80112

Phone:	1-303-649-1000 1-877-OWN-A-LIT (USA and Canada)
Fax:	1-303-649-9710
Web Site:	<a href="http://www.lasertech.com">www.lasertech.com</a>
Email:	service@lasertech.com

# LTI TruSense S100 User's Manual 3rd Edition

Copyright (c) 2015 Laser Technology, Inc. All Rights Reserved. Unauthorized duplication, in whole or in part, is strictly prohibited.

Page 1

## LTI TruSense S100 User's Manual (p/n 0144846) Change Log

---

- **3rd Edition** July 2015
  - Added LTI-brand cover page with hex design, inside cover page with copyright/patent/trademark/LTI contact information. Pages i-ii
  - Added the Change Log Page 1
  - Deleted sentence about PDF version of the LTI Limited Warranty being available on S100 CD. Page 30
  - Updated Internal Cable Diagram. Page 31
- **2nd Edition** April 2011
  - Updated Internal Cable Diagram to 7054664\_01 Cable Rear Plate. Page 31
- **1st Edition** May 2010

# Table of Contents

<b>LTI TruSense S100 User's Manual (p/n 0144846) Change Log .....</b>	<b>1</b>
<b>Introduction.....</b>	<b>3</b>
Basic Package .....	3
Developer's Kit .....	3
Accessory Items .....	3
<b>Safety Precautions .....</b>	<b>3</b>
<b>Mounting the TruSense S100 .....</b>	<b>3</b>
<b>Getting Started.....</b>	<b>4</b>
<b>Configuration .....</b>	<b>4</b>
Target Modes.....	6
Measurement Modes.....	6
Configuration Tree.....	7
<b>Error Codes .....</b>	<b>8</b>
<b>Details of 'Shutdown' and 'Ext-Trig' Control Signals .....</b>	<b>9</b>
<b>Serial Communication Protocol .....</b>	<b>10</b>
Serial Commands .....	10
Request Only .....	10
Measurement Configuration Commands .....	12
Instrument Configuration Commands .....	15
Measurement Control Commands .....	23
Measurement Output Messages.....	24
Distance Measurements .....	24
Error Messages .....	25
<b>Reference .....</b>	<b>26</b>
Application Examples .....	26
Aircraft Altitude and Mapping .....	26
Crane Collision Avoidance .....	26
Perimeter Detection .....	27
Frequently Asked Questions .....	27
<b>Specifications .....</b>	<b>29</b>
<b>Care and Maintenance .....</b>	<b>30</b>
Warranty .....	30
<b>Diagrams .....</b>	<b>31</b>
Internal Cable .....	31
External Cable .....	32
Housed Model Dimensions .....	33
OEM Model Dimensions.....	34

## Introduction

---

### Basic Package

- S100 Sensor or S100 OEM Sensor
- Communication Cable with Flying Leads
- LTI Limited Warranty

### Developer's Kit

- Power/Communication Cable
- CDROM  
(includes the Interface Software and User's Manual)

### Accessory Items

- Rear Plate Cable  
(for OEM Power/Communication cable adapt)
- 4" Tank Adaptor with Housing
- Tilt/Rotate Mounting Bracket
- Sun Shade
- DB9 to USB Adaptor

## Safety Precautions

---

- Avoid staring directly at the laser beam for prolonged periods. The TruSense S100 is designed to meet FDA eye safety requirements and is classified as eye safe to FDA (CFR21) Class I 7 mm limits, which means that virtually no hazard is associated with directly viewing the laser output under normal conditions. As with any laser device, however, reasonable precautions should be taken in its operation.
- It is recommended that you avoid staring into the transmit aperture while firing the laser. The use of optical instruments with this product may increase eye hazard.
- Never point the instrument directly at the sun. Exposing the lens system to direct sunlight, even for a brief period, may permanently damage the laser transmitter.

## Mounting the TruSense S100

---

### **IMPORTANT!**

When mounting the S100, always use a washer between housing feet and screw head.  
Do not exceed 5 inch-pounds of torque when securing.

## Getting Started

You may choose to get familiar with the sensor performance and configuration in a controlled environment. After unpacking, power on the unit with the supplied cabling and connect the DB9 pin serial connector to a serial I/O device such as a PC. A DB9 to USB adaptor is available from LTI.


Connect using either the supplied Interface software or a terminal emulation program such as Hyperterminal. Defaults=115200 baud rate, no parity, 8 data bits, 1 stop bit, no flow control.



## Configuration

You may choose to use the supplied Interface Software to configure the sensor. A terminal emulation program may also be used. For information about the Serial Communication Protocol see [Page 10](#).

Screen capture shows Continuous Measurement Mode, Closest Target Mode, and 9.1 VDC supply voltage.



Disconnect  
before powering  
down unit.


This button represents a trigger to  
awaken the S100 from Sleep Mode.  
It is not functional with this  
interface software or with  
a terminal emulation program

Stop measurement before  
selecting Setup on the toolbar.  
This will prevent screen lock.

# TruSense S100 User's Manual 3rd Edition

Copyright (c) 2015 Laser Technology, Inc. All Rights Reserved. Unauthorized duplication, in whole or in part, is strictly prohibited.

Page 5



## **Target Modes**

The TruSense S100 has five targeting modes that allow the unit to be optimized for varying measurement conditions. When selecting a mode, you will need to consider your specific situation and application.


Mode	Description
<b>First</b>	The unit takes a single measurement, transmits the output results and stops. The measurement output represents the distance to the first target the unit sees that is above the minimum detection level.
<b>Strongest</b>	The unit takes a single measurement, transmits the output results and stops. The measurement output represents the distance to the strongest target the unit sees that is above the minimum detection level.
<b>Closest</b>	Multiple-target operating mode. Allows the unit to detect multiple target reflections along the measurement sight line and output the distance to the closest target it sees. The unit continues to gather target data along the sight line, allowing weaker close-in targets to eventually be detected in front of stronger, distant targets. Example: measuring a utility pole in front of a building.
<b>Farthest</b>	Multiple-target operating mode. Allows the unit to detect multiple target reflections along the measurement sight line and output the distance to the farthest target it sees. The unit continues to gather target data along the sight line, allowing weaker distant targets to eventually be detected beyond stronger, close-in targets. Example: measuring a distant building while shooting through close-in brush.
<b>Closest and Farthest</b>	Multiple-target operating mode. The unit outputs the two distances, (1) the distance to the closest target and (2) the distance to the farthest target that the unit sees.

## **Measurement Modes**

The TruSense S100 has four measurement modes that allow the unit to be optimized for varying measurement conditions. When selecting a mode, you will need to consider your specific situation and application.

Mode	Description
<b>Single Shot</b>	The unit will take a single measurement, transmit the output result and stop. The measurement output represents the distance to the target chosen by Target Mode ( <a href="#">Page 12</a> ). To initiate a new measurement the Ext-Trig line must be deactivated and reactivated.
<b>Continuous</b>	<i>When the measurement is initiated via hardware control</i> , the unit will continue to output results as long as the Ext-Trig line is held active. <i>When the measurement is initiated via software control</i> , the unit will continue to output results until the Stop Distance Measurement command is received ( <a href="#">Page 23</a> ). The measurement output represents the distance to the target chosen by Target Mode ( <a href="#">Page 12</a> ).
<b>Fast Single Shot</b>	The instrument completes the measurement within 160 msec and the range is limited to few hundred meters. Refer to description of Single Shot Mode (above).
<b>Fast Continuous</b>	The instrument measures an average of six times per second and range is limited to few hundred meters. Refer to description of Continuous Mode (above).

## Configuration Tree



## Error Codes

When using the S100 if you experience an error, you may be able to correct it yourself. If you need technical support, please contact LTI Service.

Error Code	Explanation
<b>00</b>	Invalid Command.
<b>01</b>	No Target.
<b>10</b>	Bad Data Checksum.
<b>11</b>	Already Measuring.
<b>12</b>	Invalid Parameter.
<b>21</b>	User Settings Checksum.
<b>22</b>	Factory Settings Checksum.
<b>23</b>	BIST Test.
<b>24</b>	PLL Test.
<b>25</b>	Tx Power.
<b>26</b>	Higher Precision.
<b>27</b>	Receiver.
<b>28</b>	Supply Voltage too High.
<b>29</b>	Supply Voltage too Low.
<b>30</b>	Temperature too High.
<b>31</b>	Temperature too Low.

## Details of 'Shutdown' and 'Ext-Trig' Control Signals



---

- **Shutdown**

When this line is forced to an active state (high level) the entire LRF module is shutdown. While in the shutdown state, the Shutdown signal will draw approximately 250 uA (@5 V level) and the Power Input line will draw less than 100 uA. The unit will remain in the shutdown state as long as the Shutdown signal is held active. Following the transition of the Shutdown line to the inactive state (low level or unconnected), the LRF will fully boot up and be ready for an initial measurement or serial communications within 250 msec.

- **Ext-Trig**

This control line has dual functionality. It acts similar to the physical trigger/fire button on a conventional handheld laser rangefinder. In normal operating mode, when this line is forced to an active state (high level) the LRF module will initiate a measurement. In Single Shot Mode the laser will fire until the measurement timeout is reached ([Page 17](#)). In Continuous Mode the laser will fire as long as the Ext-Trig signal is held active. When the unit is in Sleep Mode after the Shutdown Delay expires, a short pulse (duration not less than 50 msec) on this line will wake up the unit. A pulse longer than 50 msec will wake up the unit and initiate a measurement.

Single Shot Mode	Set high longer than 50 msec.	
Continuous Mode	Set high longer than 50 msec. Hold as long as you want to output measurement results.	
	Set high at least 50 msec and then set low to output single measurement.	
Sleep Mode	Set high less than 50 msec to wake up the unit.	
	Set high longer than 50 msec to wake up the unit and initiate a measurement.	

## Serial Communication Protocol

---

- Each command and reply starts with a '\$' sign and ends with <CR><LF>.
- Default communication parameters: baud rate 115200, no parity, 8 data bits, 1 stop bit.
- Issuing mnemonic command without an associated parameter will return a current setting of the given parameter (examples follow).
- Upon applying power, the unit performs an initialization, onboard self-tests and then goes into Sleep Mode if enabled.
- Following initialization, the unit sends a message or error number/message:
  - \$OK<CR><LF> if no errors are detected.
  - \$ER,nn<CR><LF> if the self-test failed. Where 'nn' indicates the type of failure ([Page 16](#)). See [Page 19](#) for information about Error Message Output Format.
- Two methods for initiating a measurement:
  - serial command request ([Page 23](#)).
  - hardware control via the Ext-Trig control signal
- The time for an individual measurement will vary depending on the target reflectance and distance. Targets that are closer and more reflective will return a measurement quicker than targets that are farther away and less reflective. During Closest and Farthest Target Modes, the unit will attempt target acquisition for the default 2 seconds after which it will output the measurement or an error message.

## Serial Commands

The TruSense S100 responds to four types of serial commands:

- |                             |                         |
|-----------------------------|-------------------------|
| □ Request Only              | see below               |
| □ Measurement Configuration | <a href="#">Page 12</a> |
| □ Instrument Configuration  | <a href="#">Page 15</a> |
| □ Measurement Control       | <a href="#">Page 23</a> |

### Request Only

#### Instrument Identification

**Get:**           **\$ID<CR><LF>**  
**Instrument Reply:**   **\$ID,MiniULS version number date<CR><LF>**

where:           **\$**       = message identifier  
**ID**       = mnemonic for TruSense S100 Software Version  
**<CR>**   = carriage return  
**<LF>**   = line feed

Example Reply:    \$ID,miniULS 0.960 2009-10-05 14:45<CR><LF>

#### Instrument Serial Number

**Get:**           **\$SN<CR><LF>**  
**Instrument Reply:**   **\$SN, MUnnnnnn<CR><LF>**

where:           **\$**       = message identifier  
**SN**       = mnemonic for Serial Number  
**MUnnnnnn**   = instrument serial number  
**<CR>**   = carriage return  
**<LF>**   = line feed

Example Reply:    \$SN,MU012345<CR><LF>

# TruSense S100 User's Manual 3rd Edition

Copyright (c) 2015 Laser Technology, Inc. All Rights Reserved. Unauthorized duplication, in whole or in part, is strictly prohibited.

Page 11

## Instrument Status

**Get:** **\$IS<CR><LF>**

Instrument Reply: **\$IS,x1,x2,x3<CR><LF>**

where:

**\$** = message identifier

**IS** = mnemonic for Instrument Status

**x1,x2,x3** = instrument status bytes in hexadecimal notation

*x1* - Instrument Settings

bit7, bit6 - Distance Units

value 0 (0b00) - meters

value 1 (0b01) - yards

value 2 (0b10) - feet

bit5, bit4, bit3 - Measurement Mode

value 0 (0b000) - single shot mode

value 1 (0b001) - continuous mode

value 2 (0b010) - fast single shot mode

value 3 (0b011) - fast continuous mode

bit2,bit1,bit0 -Targeting Mode

value 0 (0b000) - the strongest target

value 1 (0b001) - the closest target

value 2 (0b010) - the farthest target

*x2* - Measurement Status

bit7 - measurement in progress (1), idle (0)

bit6 - measurement started by

hardware trigger (1), by software (0)

bit5 - measurement averaging in use (1), no averaging (0)

bit4 - user offset enabled (non zero) (1), no user offset (0)

bit3 - short gate enabled (non zero) (1), short gate off (0)

bit2 - long gate enabled (non zero) (1), long gate off (0)

bit1 - sleep time out enabled (1), disabled (0)

bit0 - not used

*x3* - System Warnings

bit7 - supply voltage to low (1), normal (0)

bit6 - supply voltage to high (1), normal (0)

bit5 - instrument temperature to low (1), normal (0)

bit4 - instrument temperature to high (1), normal (0)

bit3, bit2, bit1, bit0 - not used

**<CR>** = carriage return

**<LF>** = line feed

Example Reply: **\$IS,08,00,00<CR><LF>**

# TruSense S100 User's Manual 3rd Edition

Copyright (c) 2015 Laser Technology, Inc. All Rights Reserved. Unauthorized duplication, in whole or in part, is strictly prohibited.

Page 12

## Instrument Temperature

**Get:** **\$IT<CR><LF>**  
Instrument Reply: **\$IT,n.n<CR><LF>**

where: **\$** = message identifier  
**IT** = mnemonic for Instrument Temperature  
**n.n** = instrument temperature (in degrees C)  
**<CR>** = carriage return  
**<LF>** = line feed

Example Reply: **\$IT,27.6<CR><LF>**

## Supply Voltage

**Get:** **\$SV<CR><LF>**  
Instrument Reply: **\$SV,n.m<CR><LF>**

where: **\$** = message identifier  
**SV** = mnemonic for Supply Voltage  
**n.m** = supply voltage (in V)  
**<CR>** = carriage return  
**<LF>** = line feed

Example Reply: **\$SV,9.0<CR><LF>**

## Measurement Configuration Commands

### Target Mode

For information about Target Modes, see Page 6.

Set: **\$TM,tm<CR><LF>**  
Instrument Reply: **\$OK<CR><LF>**

**Get:** **\$TM<CR><LF>**  
Instrument Reply: **\$TM,tm<CR><LF>**

where: **\$** = message identifier  
**TM** = mnemonic for Target Mode  
**tm** = target mode  
            FT = First  
            ST = Strongest (default)  
            CL = Closest  
            FA = Farthest  
            CF = Closest and Farthest  
**<CR>** = carriage return  
**<LF>** = line feed

Example: **\$TM,CL<CR><LF>** Sets Target Mode to Closest.

Note: Enter **\$TM,?<CR><LF>** to display the list of Target Mode mnemonics and descriptions.

# TruSense S100 User's Manual 3rd Edition

Copyright (c) 2015 Laser Technology, Inc. All Rights Reserved. Unauthorized duplication, in whole or in part, is strictly prohibited.

Page 13

## Measurement Mode

For information about Measurement Modes, see [Page 6](#).

Set: **\$MM,mm<CR><LF>**

Instrument Reply: **\$OK<CR><LF>**

**Get:** **\$MM<CR><LF>**

Instrument Reply: **\$MM,mm<CR><LF>**

where:

**\$** = message identifier  
**MM** = mnemonic for Measurement Mode  
**mm** = measurement mode  
    SI = Single Shot (default)  
    CO = Continuous  
    FSI = Fast Single Shot  
    FCO = Fast Continuous

Note: In fast mode the instrument measures approximately six times per second and range is limited to a few hundred meters.

**<CR>** = carriage return

**<LF>** = line feed

Example: **\$MM,CO<CR><LF>**

Sets Measurement Mode to Continuous.

Note: Enter **\$MM,?<CR><LF>** to display the list of Measurement Mode mnemonics and descriptions.

## Distance Units

Set: **\$DU,u<CR><LF>**

Instrument Reply: **\$OK<CR><LF>**

Get: **\$DU<CR><LF>**

Instrument Reply: **\$DU,u<CR><LF>**

where:

**\$** = message identifier  
**DU** = mnemonic for Distance Units  
**u** = distance units  
    M = meters  
    Y = yards  
    F = feet (default)  
**<CR>** = carriage return  
**<LF>** = line feed

Example: **\$DU,M<CR><LF>**

Sets Distance Units to meters.

Gates

## **Short Gate**

The Short Gate logic allows the unit to ignore any unwanted, close-in targets that may partially obstruct the measurement beam, such as windows, brush or rain. When a short gate distance is set, the unit will ignore any targets closer than that distance. The set value is always expressed in the current distance units. If the Distance Units setting is modified after a gate value has been set, the gate will automatically be reset to 0.0.

Default value = 0.0      Short Gate logic is disabled.

Set: \$SG,n.n<CR><LF>  
Instrument Reply: \$OK<CR><LF>

Get: \$SG<CR><LF>  
Instrument Reply: \$SG,n.n<CR><LF>

where:

<b>\$</b>	= message identifier
<b>SG</b>	= mnemonic for Short Gate
<i>n.n</i>	= short gate distance in the current distance units No limitations. ±1 meter resolution.
<b>&lt;CR&gt;</b>	= carriage return
<b>&lt;LF&gt;</b>	= line feed

## **Long Gate**

The Long Gate logic allows the unit to ignore any unwanted, distant targets that may be beyond the intended target, such as a fence, building or hillside. When a long gate distance is programmed the unit will ignore any targets farther than that distance. The set value is always expressed in the current distance units. If the Distance Units setting is modified after a gate value has been set, the gate will automatically be reset to 0.0.

Default value = 0.0. Long Gate logic is disabled.

Set: \$LG,n.n<CR><LF>  
Instrument Reply: \$OK<CR><LF>

Get: \$LG<CR><LF>  
Instrument Reply: \$LG, n.n<CR><LF>

where:

<b>\$</b>	= message identifier
<b>LG</b>	= mnemonic for Long Gate
<i>n.n</i>	= long gate distance in the current distance units No limitations. ±1 meter resolution.
<b>&lt;CR&gt;</b>	= carriage return
<b>&lt;LF&gt;</b>	= line feed

## User Offset

The User Offset value is a fixed offset that is added to the actual measured distance before the result is output via the serial communications interface. This essentially allows for an adjustable "zero distance measurement point" for variations in the mechanical mounting of the unit. For example, if the unit is mounted on a moving platform and must be physically located behind the edge of the platform, but it is desired to have the distance output be referenced to the platform edge, this can be achieved by entering a user offset value. If a negative User Offset value is entered, it is possible for the unit to output a negative distance measurement. If the Distance Units setting is modified after a distance offset value has been set, the offset will automatically be reset to 0.0.

Default value = 0.0.

Set: \$OS,*n.n*  
Instrument Reply: \$OK

Get: \$0\$<CR><LF>

Instrument Reply: \$OS,n,n<CR><LF>

where:      **\$**                  = message identifier  
              **OS**                  = mnemonic for User Offset Value  
              *n.n*                  = user offset value in the current distance units.  
              <CR>                  = carriage return  
              <LF>                  = line feed

Example: \$OS,2<CR><LF> Sets the User Offset to 2.0

# Instrument Configuration Commands

## Baud Rate

Sets the serial communications data rate. The reply message to this command is sent at the previous baud rate. Thereafter all communications are at the new baud rate.

Default value = 115200 baud.

Set: \$BR,n<CR><LF>  
Instrument Reply: \$OK<CR><LF>

Get: \$BR<CR><LF>  
Instrument Reply: \$BR,*n*<CR><LF>

where:	<b>\$</b>	= message identifier
	<b>BR</b>	= mnemonic for Baud Rate
	<i>n</i>	= baud rate: 4800 9600 19200 38400 57600 115200
	<b>&lt;CR&gt;</b>	= carriage return
	<b>&lt;LF&gt;</b>	= line feed

Example: \$BR,9600<CR><LF> Sets the Baud Rate to 9,600

# TruSense S100 User's Manual 3rd Edition

Copyright (c) 2015 Laser Technology, Inc. All Rights Reserved. Unauthorized duplication, in whole or in part, is strictly prohibited.

Page 16

## Diagnose Instrument

Get: **\$DI,n<CR><LF>**  
Instrument Reply: See examples below.

where:

<b>\$</b>	= message identifier
<b>DI</b>	= mnemonic for Diagnose Instrument
<b>n</b>	= test number: 0 = all tests 1 = User Settings Checksum Test 2 = Factory Settings Checksum Test 3 = ASIC Tests 4 = Tx Power Test 5 = Precision Path Test 6 = Rx Diode Test
<b>&lt;CR&gt;</b>	= carriage return
<b>&lt;LF&gt;</b>	= line feed

Example Requests & Replies:

\$DI,1<CR><LF>	\$OK,121,User Settings Checksum
\$DI,2<CR><LF>	\$OK,122,Factory Settings Checksum
\$DI,3<CR><LF>	\$OK,123,ASIC Bist
\$DI,4<CR><LF>	\$OK,124,ASIC PII
\$DI,5<CR><LF>	\$OK,125,Tx Power
\$DI,6<CR><LF>	\$OK,126,Higher Precision
	\$OK,127,Receiver

Example Error Messages:

\$ER,00<CR><LF>	Invalid Command.
\$ER,01<CR><LF>	No Target.
\$ER,10<CR><LF>	Bad Data Checksum.
\$ER,11<CR><LF>	Already Measuring.
\$ER,12<CR><LF>	Invalid Parameter.
\$ER,21<CR><LF>	User Settings Checksum
\$ER,22<CR><LF>	Factory Settings Checksum
\$ER,23<CR><LF>	BIST Test
\$ER,24<CR><LF>	PLL Test
\$ER,25<CR><LF>	Tx Power
\$ER,26<CR><LF>	Higher Precision
\$ER,27<CR><LF>	Receiver
\$ER,28<CR><LF>	Supply Voltage too High
\$ER,29<CR><LF>	Supply Voltage too Low
\$ER,30<CR><LF>	Temperature too High
\$ER,31<CR><LF>	Temperature too Low

These error messages are examples of the Minimal Error Message format ([Page 19](#)).

# TruSense S100 User's Manual 3rd Edition

Copyright (c) 2015 Laser Technology, Inc. All Rights Reserved. Unauthorized duplication, in whole or in part, is strictly prohibited.

Page 17

## Go to Sleep

Puts the unit in Sleep Mode (minimal current consumption). The unit can only be awakened by toggling the external trigger line or disconnecting and then reconnecting the power supply.

Set:           **\$GS<CR><LF>**  
Instrument Reply:   **\$Sleep<CR><LF>**

where:       **\$**                                  = message identifier  
**GS**    = mnemonic for Go to Sleep  
**<CR>**    = carriage return  
**<LF>**    = line feed

## Measurement Time Out

The Measurement Time out is the maximum time the unit will fire the laser (while the Ext-Trig control is activated) to attempt a measurement before stopping and transmitting an output data string.

Default value = 2 seconds

Set:           **\$MT,n<CR><LF>**  
Instrument Reply:   **\$OK<CR><LF>**

Get:           **\$MT<CR><LF>**  
Instrument Reply:   **\$MT,n<CR><LF>**

where:       **\$**                                  = message identifier  
**MT**    = mnemonic for Measurement Time out  
**n**    = time out in seconds: 1 to 1800 seconds (30 minutes)  
**<CR>**    = carriage return  
**<LF>**    = line feed

Example:      **\$MT,30<CR><LF>**                                  Sets the Measurement Time out to 30 seconds

## Number of Averaged Samples

### Single Shot Mode

Default value = 1

Set:           **\$SA,n<CR><LF>**  
Instrument Reply:   **\$OK<CR><LF>**

Get:           **\$SA<CR><LF>**  
Instrument Reply:   **\$SA,n<CR><LF>**

where:       **\$**                                  = message identifier  
**SA**    = mnemonic for Averaged Samples in Single Shot Mode  
**n**    = number of averaged samples in single shot mode:  
  As n increases, the precision increases.  
  maximum = 1000  
**<CR>**    = carriage return  
**<LF>**    = line feed

Example:      **\$SA,10<CR><LF>**                                  Sets the Number of Averaged Samples in Single Shot Mode to 10.

# TruSense S100 User's Manual 3rd Edition

Copyright (c) 2015 Laser Technology, Inc. All Rights Reserved. Unauthorized duplication, in whole or in part, is strictly prohibited.

Page 18

## Continuous Mode

Default value = 1

Set:           **\$CA,n<CR><LF>**  
Instrument Reply:   **\$OK<CR><LF>**

Get:           **\$CA<CR><LF>**  
Instrument Reply:   **\$CA,n<CR><LF>**

where:       **\$**                          = message identifier  
**CA**                          = mnemonic for Averaged Samples in Continuous Mode  
**n**                          = number of averaged samples in continuous mode:  
                                As **n** increases, the precision increases.  
                                maximum = 1000  
**<CR>**                          = carriage return  
**<LF>**                          = line feed

Example:      **\$CA,20<CR><LF>**      Sets the Number of Averaged Samples in Continuous Mode to 20.

## Fast Measurement Mode

Default value = 1

Set:           **\$FA,n<CR><LF>**  
Instrument Reply:   **\$OK<CR><LF>**

Get:           **\$FA<CR><LF>**  
Instrument Reply:   **\$FA,n<CR><LF>**

where:       **\$**                          = message identifier  
**FA**                          = mnemonic for averaged samples in Fast Measurement mode  
**n**                          = number of averaged samples  
                                As **n** increases, the precision increases.  
                                maximum = 1000  
**<CR>**                          = carriage return  
**<LF>**                          = line feed

Example:      **\$FA,2<CR><LF>**      Sets Number of Averaged Samples in Fast Single Shot  
                                Measurement Mode and Fast Continuous Measurement  
                                Mode to 2.

# TruSense S100 User's Manual 3rd Edition

Copyright (c) 2015 Laser Technology, Inc. All Rights Reserved. Unauthorized duplication, in whole or in part, is strictly prohibited.

Page 19

## Output Format

### Measurement Output Format

Default value = N

Set:           **\$MO,f<CR><LF>**  
Instrument Reply:   **\$OK<CR><LF>**

Get:           **\$MO<CR><LF>**  
Instrument Reply:   **\$MO,f<CR><LF>**

where:       **\$**           = message identifier  
**MO**           = mnemonic for Measurement Output Format  
**f**           = measurement output format:  
                N = Full message  
                F = ASCII floating point range only  
**<CR>**       = carriage return  
**<LF>**       = line feed

Example:      **\$MO,F<CR><LF>**     Sets Measurement Output Format to ASCII floating point range only.

### Error Message Output Format

Default value = V

Set:           **\$EO,f<CR><LF>**  
Instrument Reply:   **\$OK<CR><LF>**

Get:           **\$EO<CR><LF>**  
Instrument Reply:   **\$EO,f<CR><LF>**

where:       **\$**           = message identifier  
**EO**           = mnemonic for Error Message Format  
**f**           = error message format:  
                N = minimal (Enn)  
                V = verbose error number and text (Enn,text)  
**<CR>**       = carriage return  
**<LF>**       = line feed

Example:      **\$EO,N<CR><LF>**     Sets Error Message Format to minimal (Enn).

## Reset Instrument

Resets the unit as if power has been applied.

Set:           **\$RI<CR><LF>**  
Instrument Reply:   **\$OK<CR><LF>**

where:       **\$**           = message identifier  
**RI**           = mnemonic for Reset Instrument  
**<CR>**       = carriage return  
**<LF>**       = line feed

## Sleep Delay

The Sleep Delay is how long the unit will wait before going into Sleep Mode following the last communication or measurement activity.

Default value = 0.

Set: \$SD,n<CR><LF>  
Instrument Reply: \$OK<CR><LF>

Get: \$SD<CR><LF>  
Instrument Reply: \$SD,n<CR><LF>

where:	<b>\$</b>	= message identifier
	<b>SD</b>	= mnemonic for Sleep Delay
	<i>n</i>	= delay in seconds: maximum = 1000 0 = never enter Sleep Mode
	<b>&lt;CR&gt;</b>	= carriage return
	<b>&lt;LF&gt;</b>	= line feed

Example: \$SD,300<CR><LF> Sets Sleep Delay to 5 minutes.

## Temperature

## **High Temperature Warning**

Default value = 55.0° C

Set: \$HTW,*n.n*  
Instrument Reply: \$OK

Get: \$HTW<CR><LF>  
Instrument Reply: \$HTW,*n.n*<CR><LF>

where:      **\$**                  = message identifier  
             **HTW**                = mnemonic for High Temperature Warning  
             *n.n*                = temperature in degrees Centigrade  
             **<CR>**               = carriage return  
             **<LF>**               = line feed

Example: \$HTW,50 Sets High Temperature Warning to 50.0°C.

## **Low Temperature Warning**

Default value = -45.0° C

Set: \$LTW,*n.n*  
Instrument Reply: \$OK

Get: \$LTW<CR><LF>  
Instrument Reply: \$LTW,*n.n*<CR><LF>

where:      \$                  = message identifier  
              LTW                = mnemonic for Low Temperature Warning  
              *n.n*                = temperature in degrees Centigrade  
              <CR>                = carriage return  
              <LF>                = line feed

Example:      \$LTW,0 Sets Low Temperature Warning to 0° C.

# TruSense S100 User's Manual 3rd Edition

Copyright (c) 2015 Laser Technology, Inc. All Rights Reserved. Unauthorized duplication, in whole or in part, is strictly prohibited.

Page 21

## User Text

Free form text. 64 characters per line and a maximum of 4 lines.

Set: **\$UT,n,text<CR><LF>**

Instrument Reply: **\$OK<CR><LF>**

Get: **\$UT,n<CR><LF>**

Instrument Reply: **\$UT,n,text<CR><LF>**

where:

**\$** = message identifier

**UT** = mnemonic for User Text

**n** = line number:

1 = first line of user text

2 = second line of user text

3 = third line of user text

4 = fourth line of user text

**text** = maximum 64 characters per line

**<CR>** = carriage return

**<LF>** = line feed

Example: **\$UT,1,example text<CR><LF>** Sets line #1 of user text to *example text*

## Delete User Text

Used to delete existing free form user text. 64 characters per line and a maximum of 4 lines.

Set: **\$DT,n<CR><LF>**

Instrument Reply: **\$OK<CR><LF>**

where:

**\$** = message identifier

**DT** = mnemonic for Delete User Text

**n** = line number:

1 = first line of user text

2 = second line of user text

3 = third line of user text

4 = fourth line of user text

**<CR>** = carriage return

**<LF>** = line feed

Example: **\$DT,3<CR><LF>** Deletes the third line of user text.

## Voltage

### Low Supply Voltage Warning

Default value = 5.5 V

Set: **\$LSW,n.n<CR><LF>**

Instrument Reply: **\$OK<CR><LF>**

Get: **\$LSW<CR><LF>**

Instrument Reply: **\$LSW,n.n<CR><LF>**

where: **\$** = message identifier

**LSW** = mnemonic for Low Supply Voltage Warning

**n.n** = voltage

**<CR>** = carriage return

**<LF>** = line feed

Example: **\$LSW,6<CR><LF>** Sets Low Supply Voltage Warning to 6.0 V.

### High Supply Voltage Warning

Default value = 9.0 V

Set: **\$HSW,n.n<CR><LF>**

Instrument Reply: **\$OK<CR><LF>**

Get: **\$HSW<CR><LF>**

Instrument Reply: **\$HSW,n.n<CR><LF>**

where: **\$** = message identifier

**HSW** = mnemonic for High Supply Voltage Warning

**n.n** = voltage

**<CR>** = carriage return

**<LF>** = line feed

Example: **\$HSW,8.5 <CR><LF>** Sets Low Supply Voltage Warning to 8.5 V.

## Measurement Control Commands

A distance measurement can be initiated by one of two methods: via a serial command request or by hardware control via the Ext-Trig control signal. The exact instrument response to either of these methods will depend upon the current Target Mode ([Page 12](#)) and Measurement Mode ([Page 13](#)).

### Start Distance Measurement

This command will make the unit respond the same as if the Ext-Trig control signal is activated and held active.

Set:           **\$GO<CR><LF>**  
Instrument Reply:   **\$OK<CR><LF>**

where:       **\$**                                  = message identifier  
**GO**    = mnemonic for Start Distance Measurement  
**<CR>**    = carriage return  
**<LF>**    = line feed

Note: For information about Measurement Output Messages see [Page 24](#).

### Stop Distance Measurement

This command is only effective if the 'GO' command has been previously sent to the unit. This command will make the unit respond the same as if the Ext-Trig control signal is deactivated.

Set:           **\$ST<CR><LF>**  
Instrument Reply:   **\$OK<CR><LF>**

where:       **\$**                                  = message identifier  
**ST**    = mnemonic for Stop Distance Measurement  
**<CR>**    = carriage return  
**<LF>**    = line feed

## **Measurement Output Messages**

When a distance measurement is initiated, the unit will always respond with one of two output messages; either the measured range or an error message. The output message will be predicated by one of three actions:

- Completion of a valid measurement.
- Deactivation of the Ext-Trig control signal during a measurement.
- Reaching the Measurement Time out limit ([Page 17](#)).

## **Distance Measurements**

Output Format: **\$DM,n.n,DU,TM,MM,Tn<CR><LF>**

Where:

<b>\$</b>	= message identifier
<b>DM</b>	= mnemonic for Distance Measurement
<i>n.n</i>	= measured distance Will be in tenths of units, with a minimum field size of one leading and one trailing digit. Example: 0.0; 0.4; 3.2; 132.0; etc.
<b>DU</b>	= Distance Units M = meters Y = yards F = feet
<b>TM</b>	= Target Mode ST = Strongest CO = Continuous CL = Closest FA = Farthest
<b>MM</b>	= Measurement Mode SI = Single Shot CO = Continuous FSI = Fast Single Shot FCO = Fast Continuous
<b>Tn</b>	= number of detected targets <i>n</i> = number of targets
<b>&lt;CR&gt;</b> = carriage return	
<b>&lt;LF&gt;</b> = line feed	

Example: \$DM,76.7,M,ST,SI,T1<CR><LF>

measured distance	= 76.7
Distance Units	= meters
Target Mode	= Strongest
Measurement Mode	= Single Shot
number of detected targets	= 1

## Error Messages

Error message format is set using the \$EO command ([Page 19](#)).

For a list of possible error codes, [Page 8](#).

Minimal

\$ER,nn<CR><LF>

Where:      **\$**      = message identifier  
                **ER**      = mnemonic for error message  
                **nn**      = indicates the error message code  
                          01 = No target acquired  
                          02 = Unstable target

<**CR**> = carriage return  
<**LF**> = line feed

Examples:     \$ER,00<CR><LF>  
                \$ER,01<CR><LF>

Verbose Error Number and Text

**\$ER,nn,error text<CR><LF>**

Where:      **\$**      = message identifier  
                **ER**      = mnemonic for error message  
                **nn,error text** = indicates the Error Message code  
                          01,no target acquired  
                          02,unstable target  
                <**CR**>      = carriage return  
                <**LF**>      = line feed

Examples:     \$ER,01,invalid command<CR><LF>  
                \$ER,01,no target acquired<CR><LF>

## Reference

### Application Examples

These examples are not absolute - sensor setup configuration varies depending on ambient conditions, target integrity, distance, constraints, and user requirements.


#### Aircraft Altitude and Mapping



Consideration: Measure the farthest target past potential sea mist or ground cover.



#### Crane Collision Avoidance



Consideration: Measure the first target encountered quickly.



## Perimeter Detection



Consideration: Measure the fence and object in front of the fence and ignore light brush 6 yards in front of the sensor.



## Frequently Asked Questions

### What measurement technique is used with the S100?

The S100 uses infrared laser light to measure distance. This invisible light is emitted from the transmit lens of the sensor, reflects off of the target and returns to the receive lens of the sensor. The exact distance is then calculated by comparing the return time to the speed-of-light constant.

### Can the sensor measure to my target?

The ability of a laser sensor to measure to a target depends on the target's reflectance and any interference between the sensor and target such as dust, fog, foliage or other. Reflectance is determined by color, opacity, distance, and the reflection angle as well as the density of any ambient interference between the sensor and the target. For example, a lighter target is more reflective than a darker one and thick dust will reduce the signal strength more than light dust.

The S100 is a highly-sensitive precision sensor and can measure to most targets within its range specification. This includes penetrating dust or fog using the Farthest target mode for instance. A good rule of thumb when measuring through fog or dust is if you can visually see the target, the sensor likely can as well.

### What is the beam diameter?

Beam Diameter at the Target = Free Aperture + (Divergence x Range)

Example:	Distance to the Target	= 100 m
	Divergence	= 3 mrad
	Free Aperture	= 23 mm

Beam Diameter at the Target =  $0.023 + (0.003 \times 100) = 323 \text{ mm}$   
Therefore, beam diameter is 32.3 cm at 100 m or 12.7 in at 328 ft.

### Which side is the Transmit lens?

Left side referencing the frontal view as shown in the figure to the right.



# TruSense S100 User's Manual 3rd Edition

Copyright (c) 2015 Laser Technology, Inc. All Rights Reserved. Unauthorized duplication, in whole or in part, is strictly prohibited.

Page 28

## The measured distance is using what reference?

Distance measurements are from the sensor front plate to the target as shown in the figure to the right.



## Does the sensor need additional protection when using outdoors?

The sunshade accessory is recommended to keep direct moisture and sun rays (heat) from coming in contact with the sensor. Direct sun rays on the sensor housing can easily heat the sensor above its operating temperature.

## What is Sleep Mode?

Sleep mode saves power when not measuring. A trigger pulse of +3 to +15 VDC, 50 msec or longer will reactivate the sensor for measuring.

## Is the beam eye safe?

Yes, but it is always a good practice not to stare directly into the transmit aperture of any light transmitting device.

## How do I protect the housing from damage in vulnerable location?

The heavy duty housing accessory is recommended.

## How do I align the S100?

An external method is required as the S100 is not equipped with alignment optics.

Alignment can be performed using an inexpensive laser pointer. Place a reflective sheet on the target to increase visibility. Reference the offset from the pointer to the transmit lens center of the S100 and this offset will be the same on the reflective sheet.



## How can I adjust the sensor after mounting?

The tilt/rotate mounting bracket accessory is recommended.

## How do I mount to measure into a tank or silo?

The heavy duty housing with dust tube accessory is recommended.

## What considerations are there when measuring through a window?

When measuring through a window, ensure the face plate of the sensor is 3 mm or closer to the window. Reflections will increase with a larger gap and could result in measurement error. This is due to "crosstalk". Crosstalk occurs when a reflection off of a very close reflector like a window is combined with the actual target reflection and could lead to an inaccurate measurement.

## Specifications

---

<u>Performance:</u>	Min. Range:	1.5 feet (0.46 meters)
	Max.Range (reflective/non-reflective):	7546/5249 feet (2300/1600 meters)
	Accuracy:	±3.3 feet (1 meter)
	Resolution:	0.1 feet (0.1 meter)
	Pulse Repetition Frequency:	1,000 Hz
	Data Output Rate	1 to 6 Hz depending on target integrity
	Target Modes:	First, Strongest, Closest, Farthest, Closest and Farthest
	Self Check:	On boot up
	Timing:	From shutdown to ready = 90 msec From sleep to ready = 0.1 msec
	Wavelength:	905 nm (near IR)
	Beam Divergence:	3 mrad (equal to 1 foot beam diameter at 328 feet or 30 cm at 100 meters)
	Free Aperture:	0.91 inch (23 mm)
	Cordset:	Male gender, straight, shielded, 6 pin Turck Picofast PSG 6M-*/S90/S618 (* = cable length)
	I/O:	Pin1 = shutdown, Pin2 = ground, Pin3 = RS232 Tx, Pin4 = RS232 RX, Pin5 = power input, Pin6 = ext trigger
	Baud Rate (min./max.):	4800/230400
	Input Power:	6 to 11 VDC
<u>Optical &amp; Electrical:</u>	Current Draw:	Measuring = 140 mA Idle = 50 mA Sleep = 30 mA

# TruSense S100 User's Manual 3rd Edition

Copyright (c) 2015 Laser Technology, Inc. All Rights Reserved. Unauthorized duplication, in whole or in part, is strictly prohibited.

Page 30

<u>Physical:</u>	Dimensions (LxWxH)	4.11 in x 3.22 in x 1.64 in (104.4 mm x 81.7 mm 41.6 mm)
Weight:	OEM = 2.7 oz (76 g) Standard = 4.8 oz (138.6 g)	
Housing & Frame Material:	Glass filled polycarbonate	
Eye Safety:	Class I, 7mm (FDA CFR21) Class 1m (IEC 60825-1:2001)	
Shock Vibration:	MIL-STD-810E	
<u>Environmental:</u>	Moisture:	IP67, NEMA 6 (S100 in housing only) <i>** S100 in housing only. Does not apply to the S100 OEM Sensor.</i>
	Operating Temperature:	-20° F to 140° F (-28° C to 60° C)

## Care and Maintenance

---

### Operating Temperature

The S100 is rated for a temperature range of -20° F to 140° F (-28° C to 60° C). Do not operate the instrument in temperatures outside of that range.

### Moisture and Dust Protection

The sun shade is recommended if the sensor is exposed to the elements. The lenses of the sensor should be kept clear of excessive contamination for optimal performance.

#### Cleaning

*Excess Moisture:* Towel off excess moisture and air dry the instrument at room temperature.

*Exterior Dirt:* Wipe exterior surfaces clean.

*Dirty lenses:* Use a brush to remove surface dust and loose particles from the transmit and receive lenses. To clean a lens, moisten it with lens cleaning solution and wipe it clean with a lens cloth or lens tissue.


## Warranty

The TruSense S100 is covered by the one-year LTI Limited Warranty. When you received your TruSense S100, you should have received the current copy of the LTI Limited Warranty. If you did not receive a copy or if you cannot locate your copy, please contact LTI.

To register your TruSense S100, please visit the LTI web site: [www.lasertech.com/Warranty-Registration.aspx](http://www.lasertech.com/Warranty-Registration.aspx)

## Diagrams

### Internal Cable




# TruSense S100 User's Manual 3rd Edition

Copyright (c) 2015 Laser Technology, Inc. All Rights Reserved. Unauthorized duplication, in whole or in part, is strictly prohibited.

Page 32

## External Cable




# TruSense S100 User's Manual 3rd Edition

Copyright (c) 2015 Laser Technology, Inc. All Rights Reserved. Unauthorized duplication, in whole or in part, is strictly prohibited.

Page 33

## Housed Model Dimensions



# TruSense S100 User's Manual 3rd Edition

Copyright (c) 2015 Laser Technology, Inc. All Rights Reserved. Unauthorized duplication, in whole or in part, is strictly prohibited.

Page 34

## OEM Model Dimensions

